

# Ethernet Link Supplement

Whozz Calling? Basic and Deluxe series units

(Version 4.0 08/13/21)

## Installation Instructions

1. Connect the unit in parallel with the phone lines coming into your building (central office or CO phone lines) before they connect to a telephone switch. Do not connect the device to extension lines (or station ports) from a telephone switch. If you are unfamiliar with these terms, please contact your telephone vendor.
2. Before powering up the unit, connect an Ethernet cable to your Local Area Network (LAN) switch or any other LAN connection available. Once the Ethernet cable is connected, power up the unit. Check the lights on the Network Switch port to ensure it shows a network connection.

## Software

**If using an application from one of our software partners**, you may only need the Ethernet Link Config program (ELConfig). It allows you to change the default IP address, other parameters, and perform troubleshooting:

[www.callerid.com/diagnostic\\_tools.php?tab=ethernet](http://www.callerid.com/diagnostic_tools.php?tab=ethernet)

**If you do not have an application from one of our software partners** and want to use our free ELPopup software, then simply download it from our website. Software for Users can be found here:

[www.callerid.com/software\\_for\\_users.php](http://www.callerid.com/software_for_users.php) Select [Download](#)

## Troubleshooting

If you do not see incoming calls pop up on your computer, you can use the [Ethernet Link Config](#) (ELConfig) diagnostic program. If you are running software that communicates with Ethernet Link hardware, close the application before running ELConfig.

If you installed the ELPopup software suite mentioned above, ELConfig is located here:

**Start ⇒ Programs ⇒ CallerID.com ⇒ Tools ⇒ ELConfig**

Or, obtain Ethernet Link Config Directly from our web site at:

[www.callerid.com/diagnostic\\_tools.php?tab=ethernet](http://www.callerid.com/diagnostic_tools.php?tab=ethernet)

Before running the Ethernet Link Config program, turn off the Caller ID application intended to work with the hardware. ELConfig should automatically detect Ethernet Link hardware installed on the LAN. If no unit is detected, make sure the Caller ID unit is powered up and connected to a working Ethernet jack. If still not detected, try the following:

- Make sure your Caller ID application is not running on the same computer. If so, turn off that application and re-launch ELConfig.
- Turn off Windows Firewall. Turn off all other 3<sup>rd</sup> party virus checkers and firewalls.
- Power down the unit. Connect the Ethernet Cable to another Ethernet jack on your network switch. Re-power unit and select the “Refresh” button next to Detected Units.

- Load ELConfig on another computer attached to the network and try detecting the unit from the new computer.

## Using Ethernet Link Config for Troubleshooting

Once the Ethernet Link hardware is detected correctly and a serial number is shown:

1. Place a phone call to one of the phone lines connected to the Ethernet Link unit. The Caller ID information should appear in the output window at the bottom on the screen. If "No CallerID" appears, check to see if Caller ID service is being provided from the phone company on that line. If nothing appears in the window, contact CallerID.com for technical support.
2. Test each phone line connected to the Ethernet Link device. If Caller ID information is displayed in the output window, then any application designed for use with Ethernet Link products should work properly.
3. If you are familiar with Ethernet configurations, you may elect to change the IP of the device to match your subnet. If so, make sure you select an IP number that is outside of any automatically assigned IP address range set on your router's DHCP server. For LAN applications do not change the Destination IP address or the Destination MAC address. These should be modified only for applications involving offsite monitoring via the internet.
4. When testing and configuration is complete, exit the ELConfig application before running any other Caller ID software.

## ELPopup Program

If you are using one of CallerID.com's software partners applications, ignore this section.

If you will be using the ELPopup program, make sure the ELConfig program is closed and then run ELPopup. If ELPopup is not already running, it is located here:

**Start ⇒ Programs ⇒ CallerID.com ⇒ ELPopup**

Place a call to one of the phone lines connected to the Ethernet Link unit. The Caller ID information should pop up on your screen. ELPopup options can be found by right-mouse-clicking the program Icon in your system tray.

You may want to place ELPopup in your Startup folder, if not done upon installation.

EL Popup can run on all Windows based computers on the LAN. To avoid other users inadvertently changing Ethernet Link parameters, we recommend that [ELConfig](#) be installed only on one computer accessed by the network administrator

## Programmers Section

Many of the devices within the CallerID.com product line will be available with a built-in network interface card, named Ethernet Link (EL). These products will function virtually the same as standard serial devices with the exception that communication between these EL devices and PCs will be via the Ethernet. These EL devices can send data to multiple PCs within a Local Area Network (LAN), or used to transmit data to a remote PC anywhere on the Internet.

EL devices transmit data in UDP packets each time a telephone event occurs. The data contained within the UDP packet consists of three distinct fields; The Unit number, Serial number, and a stream of ASCII characters. The stream conforms exactly to the standard CallerID.com data formats.

In a typical application, an EL device will be located near the incoming telephone lines and an Ethernet connection. It monitors telephone traffic and when an event occurs (such as a Caller ID signal) it sends a packet of data out the LAN. Multiple computers connected to the LAN will have an application running which will capture the packet, parse the data fields, and process the information. Many programs will use the Caller ID number to look up a customer record in a database and, in turn, "Pop-Up" the customer's information.

The EL device must be setup with the proper IP address, MAC address, and Port number. Initial setup is accomplished via the Ethernet with provided software using UDP "broadcast" packets. For software companies that elect to build in their own setup program, the command language is explained under the heading "Ethernet Link Setup" below.

### Packet Format

An EL device sends telephone data Packets over a LAN using UDP protocol. Most EL generated UDP packets are 83 characters long. Whozz Calling? "Full-featured" devices are also capable of sending detail records, which are only 52 characters long. There are other packets sent of varying lengths, but are only transmitted when devices boot-up or are invoked by a command sent to the unit. All packets start with an identifier "^^" followed by the unit number and the serial number. A "\$" identifies the remainder of the data is a standard CallerID.com data stream. It is sent as ASCII text.

Below is an example of the data contained in a packet:

```
^^<U>nnnnnn<S>nnnnnn$01 I E 0000 G A2 12/17 04:54 PM 770-263-7111 CALLERID.COM ____
```

The ^^<U> are ASCII characters, followed by six binary numbers (nnnnnn), followed by <S>, followed by six more binary numbers, an ASCII \$, and finally the ASCII data stream. Note that the 15 character name field is padded with spaces (in this example, 3 spaces).

If you were to look at the actual pack with a network snoop program such as Wireshark, the entire IP packet would look like the following.

```
0000  ff ff ff ff ff ff 06 71  11 02 05 06 08 00 45 00  .....q .....E.
0010  00 6c 22 1a 00 00 80 11  93 bd c0 a8 01 5a c0 a8  .l"..... ..Z..
0020  01 ff 0d c0 0d c0 00 58  30 fc 5e 5e 3c 55 3e 00  .....X 0.^^<U>.
0030  00 00 00 89 79 3c 53 3e  00 00 00 84 48 84 24 30  FT!.y<S> ..y.H.$0
0040  31 20 49 20 45 20 30 30  30 30 20 47 20 41 32 20  1 I E 00 00 G A2
0050  31 32 2f 31 37 20 30 34  3a 35 34 20 50 4d 20 37  12/17 04 :54 PM 7
0060  37 30 2d 32 36 33 2d 37  31 31 31 20 20 20 43 41  70-263-7 111  CA
0070  4c 4c 45 52 49 44 2e 43  4f 4d 20 20 20          LLERID.C OM
```

The Ethernet header is in **red**, the IP header is in **black**, and the UDP header is in **green** and the UDP data is in **blue**. The unit number (00000008979), is expressed in binary as 00-00-00-00-89-79. The serial number (000000844884) is similarly expressed as 00-00-00-84-48-84.

A free popup program along with source code that parses the Caller ID data packet is available from CallerID.com. The executable and all source code can be distributed royalty-free. The EL Popup application and source code can be downloaded from <http://www.callerid.com/developers.php?tab=misc>

## Programming Note

The UDP data (datagram) coming from an EL device will look similar to following.

```
^^<U>xxxxxxx<S>xxxxxxx$03 I S 0000 G A0 03/26 02:47 PM 555-867-5309 JOHN DOE
```

Since the actual Caller ID data string within a data packet always begins with a "\$" (dollar sign), a common approach is to find the first "\$" character in the entire data packet and then read the Caller ID information into the application from that point. Although, this would seem to be a good method to extract the Caller ID data, it will cause your code to fail when used with CallerID.com units produced with specific serial numbers.

Since the serial number and unit number headers in each packet are compressed from 12 digits down to 6, the original non-compressed numbers will manifest themselves as different characters in the compressed form. Specifically, when an uncompressed "24" is in a serial number or unit number, there are several instances where a "\$" is produced when compressed.

Because the serial number and unit number headers are always the same length, a good method of extracting the Caller ID data from the UPD packet is to start reading after a given number of characters. For example, if your application will not make use of the serial number and unit number, you can elect to start reading the Caller ID data after the 21st character.

## IP and MAC addresses

An EL device retains a source (its own) IP and MAC address and destination IP and MAC address in non-volatile memory. The destination addresses are defined as the address the EL device will send Ethernet data. If the data is to be sent to only one computer, the destination address will be the IP and MAC address of that computer. However, it is usually desirable for the EL device to send data to all the computers in a network. In that case, the special IP address of 255.255.255.255 and a MAC address of FF-FF-FF-FF-FF-FF are used. These are called "broadcast" addresses.

By default, an EL device has its own IP address (source address) set to 192.168.0.90. Typically, the "subnet" of a LAN will be defined by the first three groups of digits in the IP address (i.e. 192.168.0) of a device connected to the LAN. In this case, the IP addresses of all computers and devices located on a router will have these first three groups of digits the same. During setup, the EL source IP address should be changed to match the subnet. The last group (i.e. 90) can be set to any unique number except 255 or 0, but should be configured to a static IP within the router or set outside the range of the router's DHCP server. More information on DHCP ranges in routers and subnet identification can be found below in the section entitled "Setting Ethernet Link to a Unique IP Address".

## Port number

A port is simply a number that is embedded in a UDP packet header. There is a destination and a source port number in every UDP packet. The destination port is used by a computer to direct incoming packets to the intended program. For example, a program that pops-up Caller ID information could be setup to only allow packets with the port number 3520. It would ignore UDP packets with any other port number. The default factory setting is 3520 for both the destination and source port number. The destination port number can be changed, if needed, using the setup program supplied. In the above Wireshark illustration, the ports are the first four Hex numbers in green; 0D C0 0D C0. The first 0D C0 is the source port binary number; the second 0D C0 is the destination port – both equal 3520 decimal.

## Ethernet Link Setup

An EL device stores a series of operating parameters in non-volatile memory. The most commonly used values are set as the factory default. These values can be easily changed using a program provided by CallerID.com. Some software solution providers may elect to write their own setup program.

Changing a parameter value is accomplished by sending a UDP packet with special commands. All such packets begin with the characters ^^**Id**, a one character command identifier, and then the value. The structure is:

^^**Idcxxxxxxxxxxxx** - where **c** is a command identifier and the **xxx...** is the new value.

For example, sending a UDP packet of:

^^**IdU00000001234** - changes the Unit number to 1234 Hex (or 4660 decimal).

Because the state of the IP address may be unknown, setup commands are sent to the EL device with a broadcast IP address. Details describing this process are explained below.

A free setup program along with source code is available for EL devices from CallerID.com. The executable and all source code can be distributed royalty-free. Ethernet Link setup utility application and source code can be downloaded from <http://www.callerid.com/developers.php?tab=misc>

## Typical Caller ID Installations

### Multiple User Installation

The vast majority of Caller ID installations are in multi-user environments. It is common in many of these environments that the incoming phone lines are close proximity to LAN switches or other Ethernet connections. This is a convenient location to connect an EL device. Simply connect the phone lines and then attach an Ethernet cable to either the LAN switch or an available Ethernet jack.

The Caller ID application would reside on each computer intended to receive the data. When the phone rings, the device captures the Caller ID signal and transmits the data through the LAN via a broadcast UDP packet. The application allows each computer to receive the data and reacts appropriately, such as matching the caller phone number to a database record and allowing a pop-up screen.

The above configuration requires the EL to send a broadcast UDP. Set the destination IP address of the device to 255.255.255.255 to send broadcast UDP packets. More on setting EL parameters is described in the section entitled "Sending and Receiving Commands" below.

### Single User Installation

As with the multiple user installation, the EL device is usually located near both an Ethernet connection and the incoming telephone lines. If the computer receiving the Caller ID information and the EL share the same router or switch as with a Multiple User Installation, the EL can be left in the default mode to send broadcast UDP packets. Alternatively, the destination IP address of the EL device can be set to the specific IP address of the receiving computer.

## Remote Computer Monitoring

An EL can transmit on-site phone data to any off-premise computer providing that an internet connection is available. Assume that the EL is connected to a LAN along with a router providing internet access. When a packet sent by the EL specifies an external IP address, the local router transmits it to the remote destination gateway. The port number contained within the packet will be used to direct it to the correct computer on the remote network.

To accomplish this remote transmission, the EL and the remote router will need to be configured very specifically. The EL should be set to the following parameters:

1. The destination MAC address will be the MAC address of the local router
2. The destination IP address will be the static IP address assigned to the remote destination. This address can be easily determined by accessing the "What is my IP dot com" website ([www.WhatIsMyIP.com](http://www.WhatIsMyIP.com)) from the remote computer.
3. The port number set in the EL must match the port number within the remote router programmed to direct that port number to the destination computer. The default port number of 3520 is recommended. Any four digit (in Hex) port number not being used by another application can be employed, but port numbers between 0 and 1023 are reserved for special use.

Most routers contain a "redirection table" which allows it to direct incoming packets to a particular computer. This is accomplished by evaluating the port number within a packet, and based on the redirection table, sending the packet to the proper device. An additional entry would be programmed into the remote router to direct packets with the port number (i.e. 3520) to the receiving computer. Of course, this computer would have suitable software loaded set to the correct port number to accept and read these packets.

## **Sending and Receiving Commands**

The EL monitors encoded broadcast packets looking for commands directed specifically for it. These packets always start with **^^Id** and will be followed with a single character identifier. Some of these commands are simply one character while some commands are followed by data to enter or change the unit's parameters

Examples of commands accepted by EL:

- ^^Idz** - resets the unit to all default settings.
- ^^IdT0DC0** - sets the device port to 3520.

## Hex Data Format

The data sent to EL is sent in ASCII Hex. The number of Hex digits must be adhered to. For example, the MAC address is 6 characters, so 6 Hex pairs will be specified in the packet, and twelve Hex pairs will be actually delivered through the Ethernet as seen by a packet monitoring program.

In order to set the IP address to **192.168.0.90**  
or, in Hex **C0 A8 00 5A**  
A complete UDP packet would be **^^IdIC0A8005A**

The data stream shown by WireShark, or other packet monitor would be:

**5E 5E 49 64 49 43 30 41 38 30 30 35 41**  
{ **^ ^ I d I C 0 A 8 0 0 5 A** }

## Acknowledgement of Receipt

In order to acknowledge the receipt of the packet, EL will return the same packet and substitute an "ok" in place of the "Id". For example, if

- ^^Idz** is sent to EL, then
- ^^okz** is returned by the EL

## Commands to Enter or Modify Parameters

<b>M</b> xxxxxxxxxxxx	Set internal MAC address
<b>I</b> xxxxxxxx	Set internal IP address
<b>D</b> xxxxxxxx	IP address to send data
<b>T</b> xxxx	Destination Port Number
<b>P</b> xxxx	Receiving Port Number (Not used by EL device at this time)
<b>U</b> xxxxxxxxxxxx	Unit number (preset as 00000000001)
<b>C</b> xxxxxxxxxxxx	Destination MAC address (preset as <b>FF FF FF FF FF FF</b> in order for all computers on the LAN to have access to data. Set to a specific address when only one computer will receive the data)

## One Character Commands

- Z** Set the EL to default settings
- X** Return all unit parameters (via UDP packet)

The "X" command will return all parameters in the following form:

```
<M>xxxxxxxxxxxx<I>xxxxxxxx<D>xxxxxxxx<P>xxxx<T>xxxx  
<U>xxxxxxxxxxxx<C>xxxxxxxxxxxx<O>xxxxxxxxxxxx<S>xxxxxxxxxxxx
```

Remember that these are 2 character Hex pairs. Therefore, a twelve character stream is actually six, paired Hex numbers.

- N** Make a connection with host computer. The "N" command can be used to automatically load sender's IP and MAC address into the memory of the EL. This is a quick method of establishing a data connection to a single computer within a local network

## Setting Parameters in Whozz Calling? "Full-featured" Series Units

Commands sent with a leading "-" (dash) are used to set parameters, control the block/pass functionality, enter white/black list Caller ID numbers, and manually set the time and date only in Whozz Calling? "full-featured" series units. These can be single character commands used for items such as setting "toggles" (i.e. lower case **d** - turn on detail mode) within the unit, or multi-character commands for entering a number into the block list. A complete explanation of parameters, toggles, and commands can be found in the standard Whozz Calling? series manuals.

### **Single Character Command Structure**

- x Dash followed by a single character used to set a "toggle" or request a version string

Example Commands:

- d** Set detailed mode on
- b** Set first ring suppression off
- o** Set outbound monitoring on
- v** Request version string

### **Multi-Character Command Structure**

- Cnnnn...<CR> dash followed by a single letter denoting the type of command, numerical data, and then a Carriage Return (ASCII 13, Hex 0D) terminating the string.

Example Commands:

- N7702637278**<CR> Enter the number 7702637278 into the block/pass list.
- W03** Block (or pass) the inbound call on line 3.
- Z01081350**<CR> Manually set internal time clock of device to January 8, 1:50pm.

## **Finding a Ethernet Link Device**

One way to locate an EL in a subnet is to send a UDP broadcast "X". The device will respond with a list of all its parameters. The response will contain the current IP and MAC addresses within the data sent (naturally these parameters are also sent as part of the Ethernet packet structure). Additional communication is subsequently accomplished using these unique addresses. Note that broadcast messages to the EL can continue to be used if the PC will allow them.

## **Subnet Determination**

An easy way to determine the IP subnet of the LAN to which the computers of interest are connected. In a command window (formerly called a DOS Shell), simply type: **IPconfig** . A sample output is shown below:

### **Windows IP Configuration**

#### **Ethernet adapter Local Area Connection:**

```
Connection-specific DNS Suffix . . :  
IP Address. . . . . : 192.168.0.112  
Subnet Mask . . . . . : 255.255.255.0  
Default Gateway . . . . . : 192.168.0.1
```

In most cases, the first 3 sets of numbers in the IP Address shown will be the subnet. In this example the subnet is **192.168.0**. Consequently, it is recommended to set the EL to an IP address containing the subnet address plus any number extension between 1 and 254 that is not used by another device on the LAN. In this case, the EL device could be set to **192.168.0.132** since no other device has a 132 IP extension on this LAN.

In order to find the existing IP address for all devices on the LAN, you will need to access the router that controls your LAN. It will show you all the IP addresses of all computers and devices presently powered up and connected.

## **Manufacturer's Information**

CallerID.com  
5680 Oakbrook Parkway, Suite 150  
Norcross, Georgia 30093

Sales	800-240-4637
Technical Support	770-263-7111
FAX	770-263-0049
Web Site	www.CallerID.com

### **Technical Contacts:**

Keith Ruehle x109  
KRuehle@CallerID.com  
Grant Sutherland x107  
GSutherland@CallerID.com

## **Appendix A – Additional Information on Network Packets**

Ethernet protocol allows two types of transmission TCP/IP or UDP. TCP/IP is used to establish a single connection between two devices. Using a broadcast protocol, only UDP has the ability to communicate simultaneously to multiple devices on a LAN. Because the vast majority of Caller ID applications are deployed in multi-user environments, UDP is the clear choice of data transmission, and therefore is used for all EL CallerID.com devices.

UDP information is transmitted via containerized packets. Each packet contains layers of headers, checksums, routing instructions, and the actual data. One UDP packet is transmitted from a Caller ID device each time an event occurs, such as Caller ID data on an incoming telephone call. Some CallerID.com products also monitor outbound telephone calls, in addition to, detailed information for every call. A separate UDP packet will be sent immediately for each event, and the data contained will strictly adhere to standard CallerID.com formatting.

### **IP Addresses, MAC Addresses, and Port Numbers**

All devices and computers that connect to an Ethernet network have a unique MAC address. It is rare, and usually not desirable, for a MAC address of a device to change. An IP address is an assigned number to a specific device. It can be re-assigned to another device at any time. A port number is another specified parameter and is utilized to route Ethernet packets. Routers use port numbers in packets originating outside the LAN to direct them to individual computers within the LAN. Software uses port numbers to route, accept, or reject packets.

Routers and PCs automatically detect and store in a table, the MAC addresses and the corresponding IP addresses of devices connected to the LAN. Therefore, MAC addresses are not important to virtually all software applications; they require only the IP address of the device in order to communicate. When an application creates a packet with the IP address, the network card on the PC references an internal table, adds the MAC address to packet, and subsequently, sends it out on the Ethernet. The packet is presented to all the devices on the LAN, but only the device with the matching MAC address receives it.

PCs and routers use Address Resolution Protocol (ARP) to match IP addresses with MAC addresses. When a packet is seen on the Ethernet with an unknown MAC address, these devices immediately send out an ARP Request packet requesting the MAC address of the sender. The device with the matching IP address will reply with an ARP Response with this parameter. Most computers and routers on the LAN will monitor this exchange and retain the information in its ARP table.

Sometimes a PC will not allow software to send a packet to an IP address which has not been saved in its ARP table. This is sometimes the case when a new device is added to a network but it has not transmitted a packet, thus not evoking an ARP request. In this case, it may be necessary to manually enter the IP and MAC address into the ARP table. EL devices will only accept UDP packets containing its MAC address or UDP broadcast packets which contain a generic broadcast MAC address.

### **Ports**

As explained previously, port numbers are used to route packets to the proper computer behind a router and to a specific program running within a computer. In most cases, a PC will be running a number of applications simultaneously and therefore, accept a number of packets on the LAN. Each application will accept only the packets that have a designated port number. On the other hand, routers direct packets arriving from outside the LAN to a specific computer based on the port number.

## ARP Tables

Occasionally, a PC will not allow a packet to be sent in its own subnet unless the IP and MAC address is setup in its ARP table. The ARP table can be seen in a DOS window. The following commands apply.

**ARP -a** view the table

**ARP -s** [IP Address] [Mac Address] to add a static entry

For example: **ARP -s 192.168.0.1 00-22-A8-B1-99-55**

## **Appendix B – Routers and IP Address Assignment**

An IP address within a LAN can either be static and defined in a router or they can be distributed dynamically using the router's DHCP server. If enabled, the DHCP server will most likely be configured to assign IP addresses within a range. Refer to the picture below of a typical router DHCP page.

In the example pictured on the next page some devices are assigned a static IP, while others use the DHCP server to dynamically assign other devices within the range set between 192.168.0.100 and 192.168.0.199. In this LAN environment (and most other simple LANs), the subnet is defined by the first 3 groups of digits, i.e. 192.168.0.

**D-Link**  
Building Networks for People

**DI-604**  
Ethernet Broadband Router

Home **Advanced** Tools Status Help

**DHCP Server**

The DI-604 can be setup as a DHCP Server to distribute IP addresses to the LAN network.

DHCP Server  Enabled  Disabled

Starting IP Address 192 . 168 . 0 .

Ending IP Address 192 . 168 . 0 .

Lease Time

**Static DHCP**

Static DHCP is used to allow DHCP server to assign same IP address to specific MAC address.

Enabled  Disabled

Name

IP 192 . 168 . 0 .

MAC Address  -  -  -  -  -

DHCP Client

Apply  Cancel  Help

**Static DHCP Client List**

Host Name	IP Address	MAC Address
<input checked="" type="checkbox"/> fileserver1	192.168.0.120	00-18-F3-...
<input checked="" type="checkbox"/> backup	192.168.0.121	00-0E-A6-...
<input checked="" type="checkbox"/> Fileserver2	192.168.0.123	00-18-F3-...
<input checked="" type="checkbox"/> programming	192.168.0.101	00-15-58-...

**Dynamic DHCP Client List**

Host Name	IP Address	MAC Address	Expired Time
DELL4222F8	192.168.0.102	08-00-37-...	Dec/21/2007 13:42:57
Collector04	192.168.0.100	00-E0-7D-...	Dec/22/2007 08:30:08
marketing	192.168.0.112	00-19-21-...	Dec/22/2007 08:51:06
R4T1H1	192.168.0.110	00-00-C0-...	Dec/23/2007 06:26:47

EL products connected to the LAN will not be recognized by a DHCP server. Therefore, there is a possibility that the DHCP server may assign the same IP address used by an EL unit to another computer or device on the network. To avoid this potential IP conflict, you can manually assign EL units an IP address outside of the DHCP server range, or create a reserved IP address in the DHCP server for each EL unit. Using either method above prevents the DHCP server from automatically assigning the IP address set within an EL unit to another network device.

The EL unit's IP address would be defined with the same subnet, a trailing number between 1 and 254, entered as a reserved static address within the router or a trailing number outside the dynamic range of a DHCP server (in the example above, 192 . 168 . 0 . 90 would work fine).